

**BOMBAY**  
—  —  
**OUTLET**

**1885101**


**O-Brittany Viewing Stand**

**Parts List**


A. Top Assembly	1 pc
B. Legs	4 pcs
C. Allen Head Bolts	8 pcs
D. Lock Washers	8 pcs
E. Flat Washers	8 pcs
F. Allen Head Wrench	1 pc
G. Optional Allen Head Bit	1 pc

- \* Please make sure that you have all the parts and hardware indicated above before you begin assembly of this item.
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- \* This item may require periodic tightening.
- \* Take care not to overtighten bolts if using supplied Allen Head Screwdriver Bit.


**Hardware Illustrations**



C. Allen Head Bolt



D. Lock Washer



E. Flat Washer

# BOMBAY



## OUTLET

1885101

### O-Brittany Viewing Stand

1. **Attach Legs (B)** Put Top Assembly (A) upside down on a soft surface. Align the pre-threaded holes in the Legs (B) with the pre-drilled holes in corner blocks of Top Assembly (A). Secure with Allen Head Bolts (C), Lock Washers (D) and Flat Washers (E) using Allen Head Tool (F or G). See illustration.

